

CITRUS JUICER

MODEL NO.: SG-85W-2017

INSTRUCTIONS MANUAL

Read these instructions for use carefully before using the appliance and save them for

future reference.


TECHNICAL SPECIFICATIONS

Model No.: SG-85W-2017

Rated Voltage: AC 220-240V~




Rated Frequency: 50/60Hz

Rated Power: 85W

Insulation: 

PARTS IDENTIFICATION

1. Lid
2. Bigger pressure Cone
3. Small pressure cone
4. Juicer filter
5. Juicer container
6. S.s spout
7. Motor unit



WARNING:

- Do not immerse the motor unit in water nor rinse it under the tap.
- Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance.
- Do not use the appliance if the mains cord, the plug or other parts are damaged.
- If the mains cord is damaged, you must have it replaced by manufacture, or its service centre, or similarly qualified person in order to avoid a hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not allow children to use the appliance without supervision.
- Children should be supervised to ensure that they do not play with the appliance.

CAUTION:

- Always place the appliance on a flat, stable surface.
- The appliance is intended for household use only.
- Do not use the appliance much time without interruption.
- Never use any accessories or parts from other manufacturers or the manufacturers are not specifically recommended.

USING THE APPLIANCE:

This product is suitable for fruit and citrus like oranges, lemons, grapefruits, etc.. Do not use with other hard fruits which could damage the appliance.

1. Clean the cone and the jug before you use the appliance for the first time.
2. Put the plug in the wall socket.
3. Switch on the appliance by pressing a halved citrus fruit firmly onto the cone.
4. Remove the cone, take the jug from the motor unit and pour out the juice.

CLEANING:

Clean the appliance immediately after each use.

Never immerse the motor unit in water nor rinse it under the tap.

- Unplug the appliance before cleaning.
- Remove the cone and jug from the motor unit.
- Rinse the cone, jug with warm soapy water.
- Clean the motor unit with a wet cloth.

ENVIRONMENT:

Do not throw the appliance away with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this you will help to preserve the environment.

